

MINI-ROOTER PARTS LIST

| ITEM NO. | CATALOG NO. | DESCRIPTION | ITEM NO. | CATALOG NO. | DESCRIPTION |
|----------|------------------|-----------------------------------------------------|----------|--------------|----------------------------------------------------------------------------------------|
| 167195 | MR-100-1 | Complete Frame Assembly (gray) | 167934 | MR-283 | Chuck Assembly |
| 167197 | MR-100-R | Complete Frame Assembly (orange) | 167935 | MR-283-A | Chuck Body |
| 167200 | MR-101 | Frame Only (gray) | 164936 | MR-283-B | Knurled Knob |
| 167205 | MR-101-R | Frame Only (orange) | 167937 | MR-283-C | Spring |
| 167220 | MR-102 | Rubber Leg Tip (2) | 167938 | MR-283-D | Screw |
| 167240 | MR-104 | Shaft Retaining Pin | 167939 | MR-284 | Hub w/Bushing (MR-201-A-2) |
| 167250 | MR-104-A | Retaining Pin Spring | 167941 | MR-284-A | Nuts & Bolts (5) |
| 167260 | MR-104-B | Retaining Pin Collar | 167943 | MR-285 | Washer |
| 167280 | MR-105 | Shaft Spacer | 167944 | MR-286 | Shaft w/Snap Rings & Washers |
| 136230 | CTH | Tool Holder w/ Screws and Washers | 167945 | MR-286-A | Snap Rings (2) |
| 167300 | MR-200 | Complete Drum Assembly (Enclosed) | 167946 | MR-286-B | Steel Washer |
| 167330 | MR-200-O | Complete Drum Assembly (Open) | 167947 | MR-286-C | Felt Washer |
| 167310 | MR-200-2 | Drum w/Inner Drum Cage | 167966 | MR-287 | Collar w/Set Screw |
| 167445 | MR-201-2 | Drum Shell | 167968 | MR-291 | Internal Container Front |
| 167652 | MR-203-B | Edging (2) | 167971 | MR-292-A | Nuts, Lockwashers & Thumb Nuts (4) |
| 167350 | MR-201-O | Open Drum Cage | 167972 | MR-293 | Beveled Collar |
| 167444 | MR-201/202-2 | Complete Shaft & Hub Assembly (No Inner Drum Cage) | 167970 | MR-300 | Motor 1/3 hp w/GFCI, Foot Switch & Motor Switch |
| 167443 | MR-201-A-3/202-1 | Complete Shaft & Hub Assembly (For Inner Drum Cage) | 167975 | A-MR-300 | Motor w/Slip Clutch, GFCI, Foot Switch & Motor Switch |
| 167365 | MR-201-A-2 | Rear Hub Assembly w/Bushing | 136010 | GFI-10 | 10' Cord w/GFCI |
| 167470 | MR-201-A-3 | Rear Hub Assembly for Inner Drum | 168005 | MR-301-B | Belt Guard Knob |
| 167410 | MR-201-C | Screws & Nuts (5) | 167060 | MR-301-C | Washer |
| 167500 | MR-202 | Shaft (No Inner Drum Cage) | 168015 | MR-301-D | Stud Replacement |
| 167505 | MR-202-1 | Shaft (For Inner Drum Cage) | 168270 | MR-303 | V-Belt Pulley |
| 167510 | MR-202-A | Retaining Ring (2) | 136180 | MR-303-1 | Safety Clutch |
| 167520 | MR-202-B | Steel Washer | 168281 | MR-304-1 | Motor Support w/Bolts, Nuts, & Washers |
| 167530 | MR-202-C | Felt Washer | 168285 | MR-304-A | Guide Screws (2) |
| 167673 | MR-204 | Distributor Tube | 167050 | MR-304-C | Nuts, Bolts, & Washers (4) |
| 167680 | MR-204-A | Distributor Tube Rear Collar w/Set Screw | 168290 | MR-305 | Motor Support Spring |
| 167690 | MR-204-B | Distributor Tube Front Collar w/Set Screw | 136200 | MR-306 | V-Belt (45") |
| 167671 | MR-204-2 | Distributor Tube Spring & Inner Drum | 168328 | MR-307-2 | Belt Guard w/Slot for Mounting Stud |
| 167692 | MR-204-4 | Flexitube Distributor Tube Assembly | 168330 | MR-308 | Foot Switch & Motor Switch (Yellow) Assembly |
| 167710 | MR-205 | Fiber Washer (2) | 168333 | MR-308-1 | Foot Switch & Motor Switch (Yellow) Assembly for Motor # S48AC63A40P |
| 167750 | MR-206 | Front Hub | 168331 | MR-308-R | Foot Switch & Motor Switch (Red) Assembly |
| 169263 | MR-206-R | Front Hub (Silver) | 168337 | MR-308-R-1 | Foot Switch & Motor Switch (Red) Assembly for Motor # S48AC62A40P |
| 167770 | MR-207 | Round Head Cap Screws (4) | 168340 | MR-308-A | Box Only w/Cover & Screws |
| 167700 | MR-209-1 | Plastic Inner Drum Cage | 136170 | MR-308-B | Foot Pedal & Hose |
| 167790 | MR-210 | Drum Connecting Cable w/ Screws & Lock Nut | 168360 | MR-308-C | Hose Clamp (2) |
| 167795 | MR-210-A | Connecting Cable Screws & Lock Nut | 136060 | MR-308-D | Foot Pedal Only |
| 167800 | MR-215 | Distributor Tube & Front Hub Assembly | 136080 | MR-308-E | Power Switch Diaphragm |
| 167801 | MR-216 | Drum Retaining Bolt | 136050 | MR-308-F | Air Hose |
| 167802 | MR-217 | Drum Retaining Washer | 136130 | MR-308-G | Motor Switch (Yellow) |
| 167803 | MR-218 | Felt Washer | 168400 | MR-308-G-1 | Motor Switch (Yellow) for Motor # S48AC63A40P |
| 167804 | MR-219 | High Collar Lock Washer | 136210 | MR-308-G-R | Motor Switch (Red) |
| 167870 | MR-250 | "J" Drum (for 1/4" & 5/16" Cables) | 168403 | MR-308-G-R-1 | Motor Switch (Red) for Motor # S48AC62A40P |
| 167872 | MR-251-1 | Rear Shell | 168410 | MR-308-H | Rubber Boot (Open Cage Units Only) |
| 167873 | MR-252 | Round Head Machine Screw & Nut (2) | 169450 | MR-308-K | Switch Guard |
| 167890 | MR-255-1 | Front Drum Assembly for Collet Chuck | 156395 | MR-308-N | Strain Relief Nut |
| 167880 | MR-255-2 | Front Drum Assembly for Quick Grip Chuck | 131340 | CTB | Cutter Bag |
| 167901 | MR-255-A-1 | Spout Assembly for Collet Chuck | 132210 | MR-DECAL | Set of Safety Decals |
| 167902 | MR-255-A-2 | Spout Assembly for Quick Grip Chuck | 132320 | MR-DVD | Instructional DVD |
| 167905 | MR-255-B | Bushing | 168900 | PO-MR | Mini-Rooter Power Cable Feed |
| 167910 | MR-257 | Shaft for "J" Drum | 168435 | MR-GT | Guide Tube |
| 167930 | MR-260-1 | Collet Chuck Assembly | 160845 | EM3R8 | Adapter |
| 167920 | MR-260-2 | Quick Grip Chuck Knob and Tightening Handle | 166305 | ERHOI | Condensed Operating Instructions (Instructions w/Chain & Fittings, Connector, & Screw) |
| 167903 | MR-260-A | Quick Grip Chuck Grippers (3) | 168455 | MROI | Complete Operating Instructions |
| 167904 | MR-260-B | Retaining Ring | 130050 | MRC5 | Mini-Rooter Cutter Set |
| 167960 | MR-280 | Dual Drum Assembly (for 1/4", 5/16", & 3/8" Cables) | 121070 | 50EM3 | Flexicore Cable, 1/2" x 50 ft. w/ Male & Female Conn. |
| 167931 | MR-281 | Container Front | | | |
| 167932 | MR-281-A | Screws & Nuts (4) | | | |
| 167933 | MR-282 | Container Back | | | |

* *-R* Indicates for rental machine only

MINI-ROOTER SCHEMATIC DIAGRAM

