


MODEL "E" GAS RODRUNNER PARTS LIST

CAT. NO.	DESCRIPTION	CAT. NO.	DESCRIPTION
RDE-100	Frame Complete	RDE-225	Tension Spring
RDE-101	Base Only w/Axles	RDE-226	Tension Adjusting Colar w/Screw
RDE-101-A	Axle (1)	RDE-227	Snap Rings (2)
RDE-102	Guide	RDE-228	Square Head Set Screw & Lock Nut
RDE-102-A	Bolts, Nuts & Washers	RDE-229	Spacer (100-200 RPM)
RDE-106	Handle	RDE-229-1	Spacer (200-400 RPM)
RDE-107-1	Pneumatic Tire (1)	RDE-230	Bushing (200-400 RPM)
RDE-107-A	Hat-Type Push Nut (4)	RDE-301	205cc 4 Stroke Engine
RDE-108	Engine Coupling Guard	RDE-302	Drive Sprocket (100-200 RPM)
RDE-108-A	Screws for Coupling Guard (4)	RDE-302-1	Drive Sprocket (200-400 RPM)
RDE-109	Chain Guard (100-200 RPM)	RDE-303	Drive Chain (100-200 RPM)
RDE-109-1	Chain Guard (200-400 RPM)	RDE-303-1	Drive Chain (200-400 RPM)
RDE-109-A	Screws for Gear Guard (5)	RDE-310	Throttle Cable - Discontinued
RDE-200	Drive Assembly (100-200 RPM)	RDE-315	Throttle Control Assembly
RDE-200-1	Drive Assembly (200-400 RPM)	RDE-315-A	Mounting Screws (2)
RDE-201	Bearing Housing	RDE-320	Engine Coupling
RDE-201-A	Rear Ball Bearing	RDE-320-A	Coupling Sleeve
RDE-201-B	Front Bronze Bushing	RDE-325	Hot Shift Transmission
RDE-202	Bolts & Washers	RDE-326	Bolts, Nuts, Washers, Small Spacers & Large Spacers (4)
RDE-220	Drive Shaft	RDE-330	Transmission Control Handle
RDE-221	Pressure Plate (1) w/Set Screws (2) (100-200 RPM)	RDE-330-A	Control Handle Knob
RDE-221-1	Pressure Plate (200-400 RPM)	RDE-330-B	Set Screw
RDE-222	Friction Disc	RDE-330-C	Bolt & Nut
RDE-223	Drive Sprocket (100-200 RPM)	E-MRDC	Municipal Rod Drive Coupling
RDE-223-1	Drive Sprocket (200-400 RPM)	E-GCDC	Drive Coupling for "G" Cables
RDE-223-1-A	Screw (2) (200-400 RPM)	E-LCDC	Drive Coupling for "L" Cables
RDE-223-1-B	Roll Pin (2) (200-400 RPM)	TB-RDE	Tool Box
RDE-224	Thrust Bearing Set		

RODRUNNER-MODEL E GASOLINE POWERED SCHEMATIC DIAGRAM



IMPORTANT: When ordering, give Serial Number of Machine.