

## MODEL 88 PARTS LIST

**PLEASE REFERENCE THE 6-DIGIT ITEM NUMBER FOR ALL PARTS PRICING AND ORDER REQUESTS.**

| ITEM NO. | CATALOG NO. | DESCRIPTION                                           | ITEM NO. | CATALOG NO. | DESCRIPTION                                                 |
|----------|-------------|-------------------------------------------------------|----------|-------------|-------------------------------------------------------------|
| 170002   | 88-100      | Frame Complete                                        | 170375   | 88-215      | Adjustment Nut                                              |
| 170005   | 88-101      | Frame Only                                            | 170380   | 88-215-A    | Brass Slotted Head Screw 1/2" (2)                           |
| 170020   | 88-110      | Axle                                                  | 170385   | 88-220      | Friction Disc (2)                                           |
| 170025   | 88-120      | 6" Caster                                             | 170390   | 88-225      | Spacer Bushing                                              |
| 170032   | 88-121      | Caster Bolts (4)                                      | 170393   | 88-230      | Fixed Plate                                                 |
| 170040   | 88-130      | Front Bearing Post (Gray Frame)                       | 170395   | 88-235      | Spring Washer (2)                                           |
| 170035   | 88-130-1    | Front Bearing Post (Orange Frame)                     | 170405   | 88-240      | Locking Washer                                              |
| 170045   | 88-130-A    | Bushings (2)                                          | 170455   | 88-245      | Clutch Shaft 5/8" w/Key                                     |
| 170047   | 88-130-B    | Grease Fitting                                        | 170527   | 88-301-1    | 3/4 hp Motor (1725 RPM)                                     |
| 170044   | 88-130-C    | Post Adjusting Bolts, Flat Washers & Lock Washers (2) | 170515   | 88-301-2    | 1 hp Motor (1725 RPM)                                       |
| 170048   | 88-131      | Post Bolts, Nuts, & Washers (3)                       | 170540   | 88-302-1    | Gear Head Only (3.5 to 1)                                   |
| 170043   | 88-140      | Rubber Cord Wrap Tips (2)                             | 170545   | 88-302-A    | Gear Head Vent Cap                                          |
| 170049   | 88-150-1    | Handle Hinge Assembly                                 | 170555   | 88-303      | Motor Mounting Bolts (4)                                    |
| 170050   | 88-150-1-A  | Hinge Top                                             | 170560   | 88-305      | Gear Head Mounting Bolts, Nuts & Washers (4) (Gray Frame)   |
| 170060   | 88-150-1-B  | Hinge Bottom                                          | 170565   | 88-305-1    | Gear Head Mounting Bolts, Nuts & Washers (4) (Orange Frame) |
| 170070   | 88-150-1-C  | Hinge Roll Pins (2)                                   | 170581   | 88-311      | Air Foot Switch & Reverse Switch Complete                   |
| 170085   | 88-150-1-D  | Handle Locking Sleeve Stop Screw                      | 170582   | 88-311-A    | Box Only w/Cover & Screws                                   |
| 170080   | 88-155-1    | Handle Locking Sleeve                                 | 170583   | 88-311-B    | Foot Pedal & Hose                                           |
| 170090   | 88-160-2    | Handle w/Pedal Holder                                 | 170584   | 88-311-C    | Hose Clamp                                                  |
| 170091   | 88-160-2-B  | Handle Roll Pin                                       | 170585   | 88-311-D    | Foot Pedal Only                                             |
| 170093   | 88-160-3    | Handle w/Pedal Holder & Knobs                         | 136080   | 88-311-E    | Power Switch Diaphragm                                      |
| 170095   | 88-160-3-A  | Handle Socket                                         | 170587   | 88-311-F    | Air Hose Only (11 ft.)                                      |
| 170097   | 88-160-3-C  | Handle Locking Knob                                   | 136130   | 88-311-G    | Reverse Switch                                              |
| 170200   | 88-170      | 10" Wheel                                             | 170589   | 88-311-H    | Rubber Boot (Rental Units Only)                             |
| 170205   | 88-171      | Hat Type Push Nuts (2)                                | 170591   | 88-311-K    | Switch Guard                                                |
| 170210   | 88-172      | Spacer Washers (2)                                    | 170592   | 88-311-M    | Cable Tie (2)                                               |
| 170230   | 88-190      | Plastic Clutch Face Cover                             | 156395   | 88-311-N    | Strain Relief Nut                                           |
| 170350   | 88-200      | Clutch Assembly                                       | 136000   | GFI-20      | 20 ft. Power Cord w/GFCI                                    |
| 170357   | 88-201-1    | Clutch Housing w/Set Screws                           | 160060   | G-CDC       | Cable Drive Coupling w/"G" Connector for 5/8" Shaft         |
| 170360   | 88-205      | Drive Plate                                           | 161321   | L-CDC       | Cable Drive Coupling w/"L" Connector for 5/8" Shaft         |
| 170362   | 88-205-A    | Round Socket Head Bolts 1" x 1/4" (6)                 | 160970   | 7/8 L-CDC   | Cable Drive Coupling for 6L78 7/8" Cables                   |
| 170370   | 88-210      | Clutch Hub w/Roll Pin                                 | 132210   | 88-DECAL    | Set of Safety Decals                                        |
|          |             |                                                       | 132350   | 88-DVD      | Instructional DVD                                           |

# MODEL 88 SCHEMATIC DIAGRAM

