


MODEL DRZ PARTS LIST

Note: Parts shown indented beneath another part are included with the item they are listed under.

ITEM NO.	DESCRIPTION	ITEM NO.	DESCRIPTION
157610	Frame Complete for Quick Grip Chuck	157990	Motor
157620	Rubber Feet, Bolts, & Lock Nuts	158000	Motor Nuts, Lock Washers, and Spacers
157640	Rubber Leg Tip	158010	Complete Motor Guard Assembly
157650	Flanged Bushing	158020	Motor Guard Only
157660	Motor Ground Screw & Nut	158030	Wiring Harness
157730	Thrust Washer	158040	Power Switch Diaphragm
157740	4.5" Pulley	158050	Foot Pedal w/Hose
157750	V-Belt	158060	Fuse Holder w/Fuse
157760	Motor Mount Bracket	158070	Fuse
157770	Motor Mount Bracket Screws	158090	Rectifier
157780	Acorn Nuts and Washers	158100	Rectifier Nut, Screw, & Washer
157800	Plastic Drum Assembly w/Quick Grip Chuck	158110	10' Power Cord w/GFCI
157830	Plastic Drum Front	158120	Switch
157840	Screws for Plastic Drum	158130	Switch Guard
157860	Plastic Drum Rear	132210	Set of Safety Decals
157690	Drum Shaft for Plastic Drum & Open Drum Cage	130010	Handyelectric Cutter Set
157980	Fender Washer	120020	(50HE1) Flexicore Cable, 1/4" x 50 ft. with EL Basin Head
157895	Quick Grip Chuck Grippers (3)	120100	(50HE1ADH) Flexicore Cable, 5/16" x 50 ft. with Down Head
157910	Quick Grip Chuck Knob	120130	(50HE1AC) Flexicore Cable, 5/16" x 50 ft. with Female Connector
157920	Quick Grip Chuck Retaining Ring	120170	(35HE2) Flexicore Cable, 3/8" x 35 ft. with Female Connector
		140840	Band-It Splashguard

MODEL DRZ SCHEMATIC DIAGRAM



IMPORTANT: When ordering, give Serial Number of Machine.