

SENIOR POWER CABLE FEED PARTS LIST

for Sewerooter Senior and Speedrooter

Note: Parts shown indented beneath another part are included with the item they are listed under.

ITEM NO.	DESCRIPTION	ITEM NO.	DESCRIPTION
170940	SR Power Cable Feed & Guide Tube	* 55091	Bottom Roller Assembly (Serial #2465 & Up)
155007	Feed Body	155096	Bottom Plated Steel Carrier (Serial #2465 & Up)
155008	Spout	155101	Swing Pin (Serial #2465 & Up)
155009	Lifting Spring	155106	Bottom Roller Shaft (Serial #2465 & Up)
155010	Mounting Stud w/Knob & Washer	136120	Bottom Roller w/Bearing (Serial #2465 & Up)
155015	Mounting U-Bolt for SR (Thru. Serial #SR11606)	* 55126	Thrust Bearing Support Pad (Serial #2465 & Up)
* 55026	Top Roller Assembly (Serial #2465 & Up)	155130	Thrust Bearing
155031	Top Plated Steel Carrier	155135	Cable Adjustment Plate
155036	Swing Pin (Serial #2310 & Up)	155140	Plate Screws & Washers (3)
155041	Feed Roller Shaft (Serial #2465 & Up)	155180	Feed Control Disc w/Lever & Knob
136120	Feed Roller w/Bearing (Serial #2465 & Up)	155182	Lever & Knob for Control Disc
155060	Feed Pressure Knob	155190	Wave Washer
155062	Limiting Nut	155200	Feed Control Retaining Cover
* 55066	Pressure Spring (Serial #2465 & Up)	155205	Retaining Cover Screws (3)
* 55070	Ball Bearing	136110	Set of Rollers (3)
* 55076	Ball Bearing Holder (Serial #2465 & Up)	155005	Power Feed Repair Kit
155080	Top Cover Plate	132210	Set of Safety Decals
155085	Cover Screws & Washers (3)	148170	Guide Tube for Senior

*Denotes part included in PO-RK

Note: Parts for the Senior and Speedrooter Power Cable Feed WILL NOT interchange with parts for the Speedrooter 90/91/92 Power Cable Feed.

POWER CABLE FEED SCHEMATIC DIAGRAM

