


SPEEDROTER 92 PARTS LIST


Note: Parts shown indented beneath another part are included with the item they are listed under.

ITEM NO.	DESCRIPTION	ITEM NO.	DESCRIPTION
170645	Frame Complete w/Axle	156312	V-Belt Pulley
170655	Frame Only w/Axle	156315	Slip Clutch (Optional)
156036	Handle Support Knob (2)	156320	Knob for Belt Guard
156045	Stair Climber w/Belt (1)	136000	20 ft. Power Cord w/GFCI
156050	Nuts, Bolt, & Washers (2)	156330	Air Foot Switch & Reverse Switch Assembly
156055	Spacers (2)	154326	Box Only w/Cover & Screws
156061	Handle Assembly	136170	Foot Pedal & Hose
156066	Handle - Left	154328	Hose Clamp
156067	Handle - Right	136080	Power Switch Diaphragm
156075	6" Handle Wheel	136130	Reverse Switch - 3-Way
156080	Axle for Handle Wheel	170920	Switch Guard
156090	Felt Washers (2)	156395	Strain Relief Nut
156100	Bolts & Nuts (2)	156335	Belt Guard Washer
156105	Set Screws (2)	156344	Belt Guard (1/2 hp) w/Slot
170730	Rubber Cord Wrap Tip	170935	Belt Guard (3/4 hp) w/Slot
156125	Knob for Brake Rod	156309	V-Belt (64")
156130	Brake Rod Latch w/Screws	170940	Power Cable Feed Assembly
156135	10" Wheel w/Retaining Cap (1)	156350	Feed Body
156140	Wheel Retaining Cap (2)	156355	Feed Body for One Piece Feed Control Disk
156145	Axle Spacer (2)	156360	Lifting Spring
170740	Wheel Spacer Washers	156363	Guide Pins (2)
156150	Axle	155012	Mounting Stud
170750	Motor Support Spring	156370	Mounting Knob
170760	Motor Support Platform	155020	Spout & Retaining Cover
170770	Guide Screws (2)	155021	Spout for One Piece Feed Control Disk
156168	Nuts, Bolt, & Washers (4)	156380	Steel Washer
156170	Front Bearing Assembly	155026	Top Roller Assembly
156174	Front Bearing Knob	155031	Top Carrier Only
156183	Bolts, Nuts, & Washers (2)	155036	Swing Pin
170780	Drum Shaft	155041	Feed Roller Shaft
170800	Drum Shaft Retaining Bolt w/Grease Fitting	136120	Feed Roller w/Bearing
170790	Wear Washer	155060	Feed Pressure Knob
170810	Retaining Washer	155062	Limiting Nut
170820	Felt Washer	155066	Pressure Spring
170823	High Collar Lock Washer	155070	Ball Bearing
170630	Spring Distributor Tube	155076	Ball Bearing Holder
170600	Small Drum Complete (16")	155080	Top Cover
170960	Drum Shell (16")	155085	Cover Screws (3)
156219	Drum Connecting Cable (for 1/2" Cables) w/ Nut & Screws	155091	Bottom Roller Assembly
156222	Connecting Cable Nut & Screws	155096	Bottom Carrier Only
170970	Inner Drum Cage for 15" Small Drum	155100	Swing Pin
166600	Inner Drum Cage for 16" Small Drum	155106	Bottom Roller Shaft
154390	Small Drum (15") V-Belt (57")	136120	Bottom Roller w/Bearing
154395	Small Drum (16") V-Belt (59")	155130	Thrust Bearing
170610	Large Drum Complete	155135	Cable Adjustment Plate
170980	Drum Shell	155140	Plate Screws (3)
170840	Drum Hub Bearings (2)	155145	Feed Control Disc w/Lever & Knob
170880	Bushing	155182	Lever & Knob
170850	Drum Connecting Cable (for 5/8" & 3/4" Cables) w/ Nut, Screws, & Lock Washer	155150	Feed Control Disk (One Piece)
156264	Connecting Cable Nut, Screws, & Lock Washer	155190	Wave Washer
170870	Inner Drum Cage for Large Drum	155195	Wave Washer for One Piece Feed Control Disk
170873	Inner Drum Cage Bushing	136110	Set of Feed Rollers (3)
170874	Screws & Washers (6)	156008	Tool Box w/Bolts & Nuts
154248	1/2 hp Motor Complete w/Air Foot Switch, Reverse Switch, & GFCI	156006	Guide Tube
154257	3/4 hp Motor Complete w/Air Foot Switch, Reverse Switch, & GFCI	146160	Guide Tube Extension
		132210	Set of Safety Decals
		132375	Instructional DVD
		130040	Senior Cutter Set
		122080	(100EM5) Flexicore Cable, 3/4" x 100 ft. w/ Male & Female Conn.
		122040	(100EM4) Flexicore Cable, 5/8" x 100 ft. w/ Male & Female Conn.

SPEEDROOTER 92 SCHEMATIC DIAGRAM



170610 LARGE DRUM



2 PIECE FEED CONTROL DISK PARTS



IMPORTANT: When ordering, give Serial Number of Machine.