RENTAL CABLE EQUIPMENT SELECTION GUIDE

For Use In Following Pipe Sizes	Cable Diameter	Typical Applications	Machine Options							
1-1/4" - 2"	1/4"	Sinks, Bathtubs, Roofstacks	SV, PV, DRZO, PHO, ZPHO, X25	SV, PV, DRZO, PHO, ZPHO	SV, PV, DRZO, PHO, ZPHO					
1-1/2" - 2"	5/16"	Sinks, Bathtubs, Roofstacks	SV, PV, DRZO, PHO, ZPHO, X25	SV, PV, DRZO, PHO, ZPHO	SV, PV, DRZO, PHO, ZPHO					
2" - 3"	3/8"	Small Drains, Sinks, Bathtubs, Roofstacks	SV, PV, DRZO, PHO, ZPHO, MR, XP, 500	SV, PV, DRZO, PHO, ZPHO, MR, XP	MR, XP	MRP, XP				
3" - most 4" (not for roots)	1/2"	Small Drains, Inside Work	MR, XP, EJ	MR, XP, EJ	MR, XP, EJ, 500	MR, XP, EJ, 500	EJ			
3" - most 4" (not for roots)	9/16"	Small Drains with Longer Runs	ME	ME	ME	ME	ME	ME	ME	
3" - 6"	5/8"	Main Lines, Roots, Difficult Obstructions	ME, 92R, ER	ME, 92R, ER	ME, 92R, ER	ME, 92R, ER	92R, ER	92R	92R	92R
4" - 10"	3/4"	Main Lines, Roots, Difficult Obstructions	92R, ER	92R, ER	92R, ER	92R, ER	92R, ER	92R	92R	92R
3" - 10"	1-1/4" Sections	Main Lines, Roots, Difficult Obstructions	88	88	88	88	88	88	88	88
Desired Distance To Go In Pipe			25 FT.	35 FT.	50 FT.	75 FT.	100 FT.	Up to 125 FT.	Up to 150 FT.	Up to 200 FT.

Machine Abbreviations: Click Name To Visit Machine Webpage DRZO - Model DRZ EJ - Easy Rooter Junior ER - Easy Rooter ME - The Metro
MR - Mini-Rooter
PHO - Drain-Rooter-PH
PV - Power-Vee

SV - Super-Vee MR - Mini-Rooter XP - Mini-Rooter XP ZPHO - Model DRZ-PH X25 - X-25 Handy 88 - Model 88 92R - Speedrooter 92R 500 - Spin Drive