

MINI-ROOTER XP PARTS LIST


PLEASE REFERENCE THE 6-DIGIT ITEM NUMBER FOR ALL PARTS PRICING AND ORDER REQUESTS.

ITEM NO.	CATALOG NO.	DESCRIPTION	ITEM NO.	CATALOG NO.	DESCRIPTION
169005	XP-100-2	Complete Frame Assembly (Includes XP-304, XP-305, and AFH)	169340	XP-304	Motor Support w/Nuts, Bolts & Washers
169007	XP-100-R	Complete Frame Assembly (Orange) (Includes XP-304, XP-305, and AFH)	169345	XP-304-A	Nuts, Bolts & Washers (4)
169008	XP-100-BL	Complete Frame Assembly (Blue) (Includes XP-304, XP-305, and AFH)	169350	XP-304-B	Guide Screws (2)
169017	XP-101-2	Frame Only	169355	XP-305	Motor Support Spring
169018	XP-101-R	Frame Only (Orange)	136200	XP-306	V-Belt (45")
169019	XP-101-BL	Frame Only (Blue)	169400	XP-307	Belt Guard
169020	XP-102-1	Rubber Leg Tip (2)	169405	XP-308	Air Switch & Motor Switch (Yellow) Assembly
169022	XP-103	Rubber Foot, Washer & Nut (2)	169403	XP-308-1	Air Switch & Motor Switch (Yellow) Assembly for Motor # S48AC63A40P
169025	XP-104	Drum Shaft Retaining Pin	169407	XP-308-R	Air Switch & Motor Switch (Red) Assembly
169030	XP-104-A	Retaining Pin Spring	169408	XP-308-R-1	Air Switch & Motor Switch (Red) Assembly for Motor # S48AC62A40P
169035	XP-104-B	Retaining Pin Collar w/Set Screw	169410	XP-308-A	Box Only w/Cover & Screws
169037	XP-105	Shaft Spacer w/Set Screw	136170	XP-308-B	Foot Pedal & Hose
169040	XP-106	Handle Knobs w/Washers (2)	169420	XP-308-C	Cable Tie
169045	XP-107-1	Folding Handle	136060	XP-308-D	Foot Pedal Only
169046	XP-107-R	Folding Handle (Orange)	136080	XP-308-E	Power Switch Diaphragm
169044	XP-107-BL	Folding Handle (Blue)	136050	XP-308-F	Air Hose Only
169047	XP-108	Rubber Tip (2)	136130	XP-308-G	Motor Switch (Yellow)
169050	XP-110	8" Wheel w/ Retaining Cap	168400	XP-308-G-1	Motor Switch (Yellow) for Motor # S48AC63A40P
169055	XP-111	Wheel Retaining Cap	136210	XP-308-G-R	Motor Switch (Red)
169060	XP-112	Wheel Spacer (4)	168403	XP-308-G-R-1	Motor Switch (Red) for Motor # S48AC62A40P
169065	XP-116	Post Locking Knob	169450	XP-308-K	Switch Guard
169085	XP-119	Bolt w/ Lock Washer	156395	XP-308-N	Strain Relief Nut
136230	CTH	Tool Holder w/ Screws and Washers	164550	XP-309	Motor Guard w/Nylon Strip
169023	XP-115	Front Post	164555	XP-309-A	Nylon Strip
169024	XP-115-R	Front Post (Orange)	136010	GFI-10	Ground Fault Circuit Interrupter w/10' Cord
169070	XP-117	Post Support Bracket	169465	PO-XP	Complete XP Power Cable Feed
169120	XP-200	Complete Drum Assembly w/Inner Cage (Closed)	169466	PO-XP-R	Complete XP Power Cable Feed for Rental
169125	XP-200-O	Complete Drum Assembly w/Inner Cage (Open)	168904	PO-MR-101	Power Feed Body
169130	XP-201	Drum Shell	168905	PO-MR-101-A	Spout
169135	XP-201-A	Edging	168906	PO-MR-102	Lifting Spring
169133	XP-201-R	Open Drum Shell	168909	PO-MR-200	Feed Roller Assembly
169143	XP-202-1	Drum Shaft	168910	PO-MR-200-R	Feed Roller Assembly for Rental
169145	XP-202-A	Front Shaft Retaining Ring	168912	PO-MR-210	Carrier Only
169150	XP-202-B	Flat Washer	168913	PO-MR-210-R	Carrier Only for Rental
169155	XP-202-C	Felt Washer	168915	PO-MR-220	Swing Pin
169160	XP-202-D	Rear Shaft Retaining Ring	168916	PO-MR-220-R	Swing Pin for Rental
169165	XP-203	Rear Hub Assembly w/Bushing	168918	PO-MR-225	Feed Roller Shaft
169175	XP-203-B	Screws & Flanged Locknuts (5)	136150	PO-MR-703	Set of Feed Rollers (3) Note: ONLY 1 pc comes w/ PO-MR-200 & PO-MR-200-R
169180	XP-204	Distributor Tube and Inner Drum Assembly	168924	PO-MR-301	Feed Pressure Knob Assembly
168997	XP-204-1	Flexitube Distributor Tube Assembly	168929	PO-MR-315	Outer Pressure Spring
169250	XP-205	Fiber Washer (3)	168936	PO-MR-330-1	Washer
169260	XP-206	Front Hub w/Bushing (Orange)	168938	PO-MR-510	Bottom Roller Assembly Retaining Snap Ring
169263	XP-206-R	Front Hub w/Bushing (Silver)	168941	PO-MR-530	Thrust Washer
169270	XP-207	Round Head Cap Screws (4)	168944	PO-MR-602	Feed Control Disc
169280	XP-208	Distributor Tube Front Collar w/Set Screw	168945	PO-MR-601-A	Lever & Knob (For 3 Piece Feed Control Disc)
169240	XP-209-1	Inner Drum Cage	168949	PO-MR-603	Control Disc Retaining Snap Ring
169290	XP-210	Drum Connecting Cable w/ Screws & Lock Nut	168435	MR-GT	Guide Tube
169300	XP-210-A	Connecting Cable Screws & Lock Nut	169080	XP-118	Guide Tube Holder (Only included with PO-XP-R)
169360	XP-216	Inner Drum Retaining Bolt	131340	CTB	Cutter Bag
169365	XP-217	Drum Retaining Washer	132355	XP-DVD	Instructional DVD
169370	XP-218	Felt Washer	132210	XP-DECALS	Set of Safety Decals
169380	XP-219	High Collar Lock Washer	170990	AFH	Condensed Operating Instructions (Instructions w/Chain & Fittings, Connector, & Screw)
169305	XP-300	Motor 1/3 hp w/GFCI, Air Foot Switch, & Motor Switch	169480	XPOI	Complete Operating Instructions
169307	XP-300-R	Motor 1/3 hp w/GFCI, Air Foot Switch, & Motor Switch	130050	MRCS	Mini-Rooter Cutter Set
169310	XP-302	Belt Guard Retaining Knob	121040	75EM2	Flexicore Cable, 3/8" x 75 ft. w/ Female Conn.
167060	XP-302-A	Washer	121070	50EM3	Flexicore Cable, 1/2" x 50 ft. w/ Female Conn.
169330	XP-303	V-Belt Pulley			
136180	XP-303-1	Safety Slip Clutch			



*"-R" Indicates for rental machine only

MINI-ROOTER XP SCHEMATIC DIAGRAM

PO-XP POWER CABLE FEED



XP-201-R OPEN DRUM



REAR VIEW

